

3900-A Aerial Service Wire Closure

1.0 Closure Installation

-Fasten closure to vertical surface with cable entry ports facing down.

2.0 Cable Preparation

-Prepare cable ends as shown in Fig.1.


Fig.1



3.0 Splice Assembly

- -Prepare splice as per standard company practice.
- -Install completed splice into closure body as shown in Fig.2.
- -Snap Cover Closed.

Fig.2



Issue: Dec. 7th 1993

Important Notice

All Statements, technical information and recommendations related to the Seller's products are based on information believed to be reliable, but the accuracy or completeness thereof it not guaranteed. Before utilizing the product, the user should determine the suitability of the product for its intended use. The user assumes all risks and liability whatsoever in connection with such use.

Any statements or recommendations of the Seller which are not contained in the Seller's current publications shall have no force or effect unless contained in an agreement signed by an authorized officer of the Seller. The statements contained herein are made in lieu of all warranties, express or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose which warranties are hereby expressly disclaimed.

SELLER SHALL NOT BE LIABLE TO THE USER OR ANY OTHER PERSON UNDER ANY LEGAL THEORY, INCLUDING BUT NOT LIMITED TO NEGLIGENCE OR STRICT LIABILITY, FOR ANY INJURY OR FOR ANY DIRECT OR CONSEQUENTIAL DAMAGES SUSTAINED OR INCURRED BY REASON OF THE USE OF ANY OF THE SELLER'S PRODUCTS THAT WERE DEFECTIVE.

CV-0002-2563-7

0540I.DOC

(c) 1993 3M CANADA

3M Telecom Systems Group

P.O. Box 5757 London, Ontario N6A 4T1 (519) 451-2500

